



IT-30004

QuietCool Adjustable Thermostat
with Humidity Control and
Built-in Fire Shut Off Fuse



PRODUCT FEATURES

- Adjustable thermostat between 60°F and 120°F
- Humidistat setting between 30% to 90%
- Rated for up to 4 Amps
- Only for use with QuietCool power ventilators

WIRING INSTRUCTIONS

DANGER: Electrical connections on all wiring must be done by a qualified electrician in accordance with all local codes and standards, including fire-rated construction. Failure to complete installation properly can result in fire or even death.


WARNING: Turn off the electrical current to the unit before attempting any service work.

**FOLLOW ALL WIRING DIAGRAMS AND ALL INSTRUCTIONS CAREFULLY.
CONNECT TO 115-120V CIRCUIT ONLY.**

1. Turn off power to unit at breaker box.
2. If you are replacing an existing thermostat or humidistat.
3. Disconnect wiring from the existing thermostat or humidistat.
4. Remove old thermostat and humidistat and box from fan at conduit connection in box.
5. Connect one black wire from the humidistat to the black wire of the incoming power supply.
6. Connect the other black wire from the humidistat to the black motor wire.
7. Connect the white wire from the power supply to the white motor wire.
8. Attach the ground wire from the incoming power supply and the ground wire from the motor to the ground screw on the control box.

CAUTION: Incorrect wiring can cause motor failure and possible fire.

9. Replace cover on the thermostat/humidistat. Check all connections to be sure there are no exposed conductors.
10. Set the temperature/humidistat control at your desired temperature and humidity.
11. Restore power to the circuit.



IT-30004

QuietCool Adjustable Thermostat with
Humidity Control and Built-in Fire Shut Off Fuse

